

MODEL	DIAPHRAGM & GASKET SET	REPAIR KIT
HU-1C	DG-2HU	RK-14HU
HU-2B	DG-2HU	RK-14HU
HU-3A	DG-2HU	RK-14HU
HU-3C	DG-2HU	RK-14HU
HU-3G	DG-2HU	RK-14HU
HU-4A	DG-2HU	RK-14HU
HU-4B	DG-2HU	RK-14HU
HU-6A	DG-2HU	RK-14HU
HU-7A	DG-2HU	RK-14HU
HU-7B	DG-3HU	RK-16HU
HU-8A	DG-2HU	RK-14HU
HU-8B	DG-2HU	RK-14HU
HU-8C	DG-2HU	RK-14HU
HU-9A	DG-2HU	RK-14HU
HU-9C	DG-2HU	RK-14HU
HU-10A	DG-2HU	RK-14HU
HU-10B	DG-2HU	RK-14HU
HU-10C	DG-2HU	RK-15HU
HU-11A	DG-2HU	RK-14HU
HU-11B	DG-2HU	RK-14HU
HU-11D	DG-2HU	RK-14HU
HU-12A	DG-2HU	RK-14HU
HU-12B	DG-2HU	RK-14HU
HU-12C	DG-2HU	RK-14HU
HU-13A	DG-2HU	RK-14HU
HU-14A	DG-2HU	RK-14HU
HU-14C	DG-2HU	RK-14HU
HU-15A	DG-2HU	RK-14HU
HU-15D	DG-2HU	RK-14HU
HU-15E	DG-2HU	RK-14HU
HU-15F	DG-2HU	RK-14HU
HU-16A	DG-2HU	RK-14HU
HU-16B	DG-2HU	RK-14HU
HU-17A	DG-2HU	RK-14HU
HU-18A	DG-2HU	RK-14HU
HU-18C	DG-2HU	RK-14HU
HU-19D	DG-2HU	RK-14HU
HU-19E	DG-2HU	RK-15HL
HU-19F	DG-2HU	RK-15HU
HU-20A	DG-2HU	RK-14HU
HU-20C	DG-2HU	RK-14HU
HU-21A	DG-2HU	RK-14HU
HU-22A	DG-2HU	RK-14HU
HU-24A	DG-2HU	RK-14HU
HU-24B	DG-2HU	RK-14HU
HU-24C	DG-2HU	RK-14HU
HU-25A	DG-2HU	RK-14HU
HU-25C	DG-2HU	RK-14HU
HU-26A	DG-2HU	RK-14HU
HU-26B	DG-2HU	RK-14HU
HU-27A	DG-2HU	RK-14HU
HU-28A	DG-2HU	RK-14HU

MODEL	DIAPHRAGM & GASKET SET	REPAIR KIT
HU-29A	DG-2HU	RK-14HU
HU-30A	DG-2HU	RK-14HU
HU-32A	DG-2HU	RK-14HU
HU-32B	DG-2HU	RK-14HU
HU-33C	DG-2HU	RK-14HU
HU-34A	DG-2HU	RK-14HU
HU-34B	DG-2HU	RK-14HU
HU-35C	DG-2HU	RK-14HU
HU-36B	DG-2HU	RK-14HU
HU-37A	DG-2HU	RK-14HU
HU-37B	DG-2HU	RK-14HU
HU-37C	DG-2HU	RK-15HU
HU-38A	DG-2HU	RK-14HU
HU-39B	DG-2HU	RK-14HU
HU-40A	DG-2HU	RK-14HU
HU-40B	DG-2HU	RK-14HU
HU-40C	DG-2HU	RK-14HU
HU-40D	DG-2HU	RK-15HU
HU-42A	DG-2HU	RK-14HU
HU-42B	DG-2HU	RK-14HU
HU-43A	DG-2HU	RK-14HU
HU-44A	DG-2HU	RK-14HU
HU-45A	DG-2HU	RK-14HU
HU-46A	DG-2HU	RK-14HU
HU-47A	DG-2HU	RK-14HU
HU-48A	DG-2HU	RK-14HU
HU-50A	DG-2HU	RK-14HU
HU-51A	DG-2HU	RK-14HU
HU-51B	DG-2HU	RK-15HU
HU-51C	DG-2HU	RK-14HU
HU-52A	DG-2HU	RK-14HU
HU-52B	DG-2HU	RK-14HU
HU-52C	DG-2HU	RK-15HU
HU-53A	DG-2HU	RK-14HU
HU-53B	DG-2HU	RK-14HU
HU-54A	DG-2HU	RK-14HU
HU-54B	DG-2HU	RK-14HU
HU-54D	DG-2HU	RK-14HU
HU-54E	DG-2HU	RK-14HU
HU-54F	DG-2HU	RK-16HU
HU-55A	DG-2HU	RK-14HU
HU-56A	DG-2HU	RK-14HU
HU-57B	DG-2HU	RK-14HU
HU-57C	DG-2HU	RK-15HU
HU-58A	DG-2HU	RK-15HU
HU-58B	DG-2HU	RK-15HU
HU-58C	DG-2HU	RK-15HU
HU-58D	DG-2HU	RK-15HU
HU-59A	DG-2HU	RK-14HU
HU-60A	DG-2HU	RK-14HU
HU-61A	DG-2HU	RK-14HU
HU-62A	DG-2HU	RK-14HU

MODEL	DIAPHRAGM & GASKET SET	REPAIR KIT
HU-62B	DG-2HU	RK-14HU
HU-63A	DG-2HU	RK-14HU
HU-63B	DG-2HU	RK-15HU
HU-63C	DG-2HU	RK-15HU
HU-64A	DG-2HU	RK-14HU
HU-64C	DG-2HU	RK-14HU
HU-64D	DG-2HU	RK-14HU
HU-65B	DG-2HU	RK-14HU
HU-65C	DG-2HU	RK-14HU
HU-66A	DG-2HU	RK-14HU
HU-67A	DG-2HU	RK-14HU
HU-67B	DG-2HU	RK-15HU
HU-67C	DG-2HU	RK-16HU
HU-68A	DG-2HU	RK-14HU
HU-69A	DG-2HU	RK-14HU
HU-70A	DG-2HU	RK-14HU
HU-70B	DG-2HU	RK-15HU
HU-71A	DG-2HU	RK-14HU
HU-71B	DG-2HU	RK-14HU
HU-72A	DG-2HU	RK-14HU
HU-72B	DG-2HU	RK-14HU
HU-73A	DG-2HU	RK-17HU
HU-73B	DG-2HU	RK-17HU
HU-74A	DG-3HU	RK-16HU
HU-75A	DG-2HU	RK-15HU
HU-76A	DG-2HU	RK-15HU
HU-77A	DG-4HU	RK-18HU
HU-78A	DG-2HU	RK-17HU
HU-79A	DG-4HU	RK-18HU
HU-80A	DG-2HU	RK-15HU
HU-81A	DG-2HU	RK-15HU
HU-81B	DG-2HU	RK-15HU
HU-82A	DG-2HU	RK-15HU
HU-82B	DG-2HU	RK-15HU
HU-83A	DG-2HU	RK-19HU
HU-83B	DG-2HU	RK-19HU
HU-83C	DG-5HU	RK-19HU
HU-83D	DG-2HU	RK-19HU
HU-83E	DG-2HU	RK-15HU
HU-83F	DG-2HU	RK-15HU
HU-84A	DG-3HU	RK-16HU
HU-84B	DG-3HU	RK-16HU
HU-84C	DG-3HU	RK-16HU
HU-84D	DG-2HL	RK-15HU
HU-86A	DG-4HU	RK-18HU
HU-87A	DG-3HU	RK-16HU
HU-87B	DG-3HU	RK-16HU
HU-88A	DG-4HU	RK-18HU
HU-88B	DG-4HU	RK-18HU
HU-89A	DG-4HU	RK-18HU
HU-89B	DG-4HU	RK-18HU
HU-90A	DG-4HU	RK-18HU

MODEL	DIAPHRAGM & GASKET SET	REPAIR KIT
HU-90B	DG-4HU	RK-18HU
HU-91A	DG-4HU	RK-18HU
HU-92A	DG-4HU	RK-18HU
HU-94A	DG-4HU	RK-18HU
HU-94B	DG-4HU	RK-18HU
HU-95A	DG-4HU	RK-18HU
HU-96A	DG-4HU	RK-18HU
HU-97A	DG-3HU	RK-16HU
HU-98A	DG-4HU	RK-18HU
HU-99B	DG-4HU	RK-18HU
HU-99C	DG-4HU	RK-18HU
HU-99D	DG-4HU	RK-18HU
HU-99E	DG-4HU	RK-21HU
HU-100A	DG-4HU	RK-18HU
HU-100B	DG-4HU	RK-18HU
HU-100C	DG-4HU	RK-18HU
HU-100D	DG-4HU	RK-21HU
HU-101A	DG-2HU	RK-14HU
HU-101B	DG-2HU	RK-14HU
HU-102A	DG-2HU	RK-14HU
HU-102B	DG-2HU	RK-14HU
HU-103A	DG-4HU	RK-21HU
HU-103B	DG-4HU	RK-21HU
HU-104A	DG-2HU	RK-14HU
HU-104B	DG-2HU	RK-14HU
HU-105A	DG-2HU	RK-14HU
HU-106A	DG-4HU	RK-21HU
HU-107A	DG-4HU	RK-21HU
HU-107B	DG-4HU	RK-21HU
HU-107C	DG-4HU	RK-21HU
HU-107D	DG-4HU	RK-21HU
HU-107E	DG-4HU	RK-21HU
HU-108A	DG-4HU	RK-21HU
HU-108B	DG-4HU	RK-21HU
HU-108C	DG-4HU	RK-21HU
HU-108D	DG-4HU	RK-21HU
HU-108E	DG-4HU	RK-21HU
HU-109A	DG-4HU	RK-21HU
HU-110A	DG-4HU	RK-21HU
HU-111A	DG-5HU	RK-19HU
HU-112A	DG-4HU	RK-21HU
HU-112B	DG-4HU	RK-21HU
HU-112C	DG-4HU	RK-21HU
HU-112D	DG-4HU	RK-21HU
HU-112E	DG-4HU	RK-21HU
HU-113A	DG-4HU	RK-21HU
HU-113B	DG-4HU	RK-21HU
HU-113C	DG-4HU	RK-21HU
HU-114A	DG-4HU	RK-21HU
HU-114B	DG-4HU	RK-21HU
HU-114C	DG-4HU	RK-21HU
HU-114D	DG-4HU	RK-21HU

MODEL	DIAPHRAGM & GASKET SET	REPAIR KIT
HU-114E	DG-4HU	RK-21HU
HU-115A	DG-6HU	RK-23HU
HU-115B	DG-6HU	RK-23HU
HU-116A	DG-2HU	RK-15HU
HU-116B	DG-2HU	RK-15HU
HU-117A	DG-6HU	RK-22HU
HU-117B	DG-6HU	RK-22HU
HU-118A	DG-4HU	RK-21HU
HU-119A	DG-4HU	RK-21HU
HU-120A	DG-4HU	RK-21HU
HU-121A	DG-6HU	RK-23HU
HU-121B	DG-6HU	RK-24HU
HU-121C	DG-6HU	RK-24HU
HU-122A	DG-11HU	RK-31HU
HU-123A	DG-11HU	RK-31HU
HU-124A	DG-11HU	RK-31HU
HU-125A	DG-11HU	RK-31HU
HU-126A	DG-11HU	RK-31HU
HU-127A	DG-11HU	RK-31HU
HU-128A	DG-11HU	RK-31HU
HU-129A	DG-11HU	RK-31HU
HU-130A	DG-11HU	RK-31HU
HU-131A	DG-10HU	RK-30HU
HU-132A	DG-11HU	RK-11HU
HU-133A	DG-10HU	RK-30HU
HU-134A	DG-11HU	RK-31HU
HU-135A	DG-11HU	RK-31HU
HU-136A	DG-2HU	RK-15HU
HU-137	Call	Call