

<b>MODEL</b>	<b>DIAPHRAGM &amp; GASKET SET</b>	<b>REPAIR KIT</b>
HE-1A	DG-1HK	RK-1HE
HE-2A	DG-1HK	RK-1HE
HE-3A	DG-1HK	RK-1HE
HE-4A	DG-1HK	RK-1HE
HE-5A	DG-1HK	RK-1HE
HE-6A	DG-1HK	RK-1HE
HE-7A	DG-1HK	RK-1HE
HE-8A	DG-1HK	RK-1HE
HE-9A	DG-1HK	RK-1HE
HE-9B	DG-1HK	RK-1HE
HE-9C	DG-1HK	RK-1HE
HE-10A	DG-1HE	RK-1HE
HE-11A	DG-1HK	RK-1HE
HE-12A	DG-1HK	RK-1HE