

**MODEL DIAPHRAGM & GASKET SET REPAIR KIT**

HK-3D	DG-1HK	RK-36HK
HK-5C	Call	Call
HK-7C	Call	Call
HK-9C	Call	Call
HK-10D	DG-1HK	RK-32HK
HK-10E	DG-1HK	RK-32HK
HK-12A	DG-1HK	RK-32HK
HK-12B	DG-1HK	RK-32HK
HK-12C	DG-1HK	RK-32HK
HK-13A	DG-1HK	RK-34HK
HK-13C	DG-1HK	RK-34HK
HK-13D	DG-1HK	RK-34HK
HK-14B	DG-1HK	RK-33HK
HK-14C	DG-1HK	RK-33HK
HK-14D	DG-1HK	RK-33HK
HK-15B	DG-1HK	RK-32HK
HK-15C	DG-1HK	RK-32HK
HK-15D	DG-1HK	RK-32HK
HK-15E	DG-1HK	RK-32HK
HK-16B	DG-1HK	RK-36HK
HK-16C	DG-1HK	RK-36HK
HK-16D	DG-1HK	RK-32HK
HK-19A	DG-1HK	RK-32HK
HK-19C	DG-1HK	RK-32HK
HK-20A	DG-1HK	RK-32HK
HK-20B	DG-1HK	RK-32HK
HK-20C	DG-1HK	RK-32HK
HK-21A	DG-1HK	RK-32HK
HK-21B	DG-1HK	RK-34HK
HK-21C	DG-1HK	RK-34HK
HK-23A	DG-1HK	RK-32HK
HK-23B	DG-1HK	RK-32HK
HK-23C	DG-1HK	RK-32HK
HK-23D	DG-1HK	RK-32HK
HK-23E	DG-1HK	RK-32HK
HK-25A	DG-1HK	RK-36HK
HK-25B	DG-1HK	RK-36HK
HK-27A	DG-1HK	RK-36HK
HK-27B	DG-1HK	RK-32HK
HK-28A	DG-1HK	RK-36HK
HK-28B	DG-1HK	RK-32HK
HK-28C	DG-1HK	RK-32HK
HK-29A	DG-1HK	RK-32HK
HK-29B	DG-1HK	RK-33HK
HK-30A	DG-1HK	RK-34HK
HK-30B	Call	Call
HK-35A	DG-1HK	RK-34HK
HK-36A	DG-1HK	RK-35HK
HK-37A	DG-1HK	RK-34HK

**MODEL    DIAPHRAGM & GASKET SET    REPAIR KIT**

HK-38A	DG-1HK	RK-32HK
HK-39A	DG-1HK	RK-32HK
HK-40A	DG-1HK	RK-32HK
HK-40B	DG-1HK	RK-34HK
HK-41A	DG-1HK	RK-35HK
HK-42A	DG-1HK	RK-33HK
HK-42B	DG-1HK	RK-1HK
HK-43A	DG-1HK	RK-33HK
HK-43B	DG-1HK	RK-33HK
HK-44A	DG-1HK	RK-32HK
HK-45A	DG-2HK	RK-37HK