

MODEL	DIAPHRAGM & GASKET SET	REPAIR KIT
HT-1A	DG-1HT	RK-1HT
HT-2A	DG-1HT	RK-1HT
HT-2B	DG-1HT	RK-1HT
HT-3A	DG-1HT	RK-1HT
HT-4A	DG-2HS/T	RK-2HT
HT-4B	DG-2HS/T	RK-2HT
HT-4C	DG-2HS/T	RK-2HT
HT-5A	DG-3HS/T	RK-3HT
HT-6A	DG-2HS/T	RK-2HT
HT-6B	DG-2HS/T	RK-2HT
HT-7A	DG-7HS/T	RK-3HT
HT-7B	DG-7HS/T	RK-3HT
HT-8A	DG-3HS/T	RK-1HT
HT-9A	DG-2HS/T	RK-18HS
HT-10A	DG-2HS/T	RK-2HS
HT-11A	DG-7HS/T	RK-28HS
HT-11B	DG-7HS/T	RK-28HS
HT-11C	DG-7HS/T	RK-28HS
HT-11D	DG-7HS/T	RK-28HS
HT-12A	DG-7HS/T	RK-28HS
HT-12B	DG-7HS/T	RK-28HS
HT-12C	DG-7HS/T	RK-28HS
HT-12D	DG-7HS/T	RK-28HS
HT-12E	DG-7HS/T	RK-28HS
HT-13A	N/A	RK-4HT
HT-14A	DG-3HS/T	RK-29HS
HT-15A	DG-7HS/T	RK-28HS
HT-18A	DG-7HS/T	RK-28HS
HT-20A	DG-3HS/T	RK-1HT